
























Elektrische openers Aansluitschema

A4000 / A5000 / FT500

	Anschluss	Spannung	Strom	Einschaltduer
Typ A 	 Reihen- schaltung	6 V AC/DC ± 15% 6-12 V AC/DC	0,5 A 0,5-1 A	 ∞  <1min.
	 Parallel- schaltung	12 V AC/DC ± 15% 12-24 V AC/DC	0,3 A 0,3-0,5 A	 ∞  <1min.
Typ B 	 Reihen- schaltung	12 V AC/DC ± 15% 12-24 V AC/DC	0,2 A 0,2-0,4 A	 ∞  <1min.
	 Parallel- schaltung	24 V AC/DC ± 15% 24-48 V AC/DC	0,1 A 0,1-0,2 A	 ∞  <1min.
Typ E 	 	8-11 V AC/DC 11-28 V AC/DC	0,2 A 0,05 A	 ∞  ∞
Typ F 	 	12 V DC ± 15%	0,2 A	 ∞

Versie 2024 – Rev. 1